



**ADVENTURE  
FURTHER®**

**FLEX ERA 3 FOG LIGHT MOUNT  
18-22 JEEP JL WRANGER | JT GLADIATOR  
FOR SPORT BUMPER - #7473, #97148**

## INSTALLATION INSTRUCTIONS

**IMPORTANT:** Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.



2018-2022 JEEP JL, JT, STANDARD PLASTIC BUMPER (SPORT, SPORT-S)

### ASSEMBLY INSTRUCTIONS

TOOLS NEEDED:  
METRIC ALLEN KEY SET

1. [Image of fog light housing]
2. [Image of removing screws and washers from the housing] REMOVE SCREWS AND WASHERS
3. [Image of fog light with brackets] STARTING WITH THE DRIVER'S SIDE, POSITION THE BRACKETS ACCORDING TO THE DIAGRAM.
4. [Image of serrated lock washer being inserted] POSITION SERRATED LOCK WASHER BETWEEN BRACKET AND HOUSING TO ENSURE THAT THE HOLES ARE ALIGNED TO HOUSING
5. [Image of Allen cap screw and washer being inserted] USING ALLEN CAP SCREW & WASHER, MOUNT BRACKET TO HOUSING
6. [Image of loosely securing bracket and lock washer] LOOSELY SECURE BRACKET & LOCK WASHER TO HOUSING (FOR FINAL ANGLE ADJUSTMENT)
7. [Image of repeating hardware mounting on the other side] REPEAT HARDWARE MOUNTING ON OTHER SIDE.
8. [Image of loosely securing bracket and lock washer on the other side] LOOSELY SECURE BRACKET & LOCK WASHER TO HOUSING (FOR FINAL ANGLE ADJUSTMENT)
9. [Image of fog light with shrouds] (PASSENGER SIDE) (DRIVER SIDE)  
POSITION THE SHROUDS SO THAT THE TRIANGULAR OPENING MATCHES THE FRONT PROFILE OF THE LIGHT.
10. [Image of fog light with shrouds snapped in] (PASSENGER SIDE) (DRIVER SIDE)  
SIMPLY SNAP THE SHROUDS INTO POSITION

### LIGHT INSTALLATION INSTRUCTIONS

TOOLS NEEDED:  
PHILIPS SCREWDRIVER

1. USING THE FACTORY HARDWARE, SIMPLY ALIGN THE FOG LIGHT AND FIX INTO POSITION.
2. WITH THE FOG LIGHT ASSEMBLY INSTALLED, USING THE LIGHT MOUNTING SCREWS, FIND THE DESIRED PITCH ANGLE AND FIRMLY SECURE THE LIGHT IN PLACE.

### HARNESS ADAPTER INSTALL - #30546

3127CA HARNESS FOR HIGH POWER MODE

(2) #30546 OEM HARNESS ADAPTERS

OEM (H16) DRIVER

OEM (H16) PASSENGER